

Replacement Inkjet Cartridge

Fullmark®

Compatibility Guide



CARTRIDGE MODEL

EPSON PRINTER	FM Cartridge No.	E046BK	E047CN	E047MA	E047YW	E049BK	E049CN	E049MA	E049YW	E049LC	E049LM	E054BK	E054CN	E054MA	E054YW	E054RD	E054MB	E054BL	E063BK	E063CN	E063MA	E063YW	E073BK	E073CN	E073MA	E073YW	E073NBK	E073NCN	E073NMA	E073NYW	E082BK	E082CN	E082MA	E082YW	E082LC	E082LM			
	OEM Cartridge No.	T0461	T0472	T0473	T0474	T0491	T0492	T0493	T0494	T0495	T0496	T0541	T0542	T0543	T0544	T0547	T0548	T0549	T0631	T0632	T0633	T0634	T0731	T0732	T0733	T0734	T0731N	T0732N	T0733N	T0734N	T0821	T0822	T0823	T0824	T0825	T0826			
ALL-IN-ONE	Stylus CX 3500	●	●	●	●														●	●	●	●																	
	Stylus CX 3700																			●	●	●	●																
	Stylus CX 3900																			●	●	●	●																
	Stylus CX 4100																			●	●	●	●																
	Stylus CX 4500	●	●	●	●															●	●	●	●																
	Stylus CX 4700																			●	●	●	●																
	Stylus CX 5500																			●	●	●	●																
	Stylus CX 5700F																			●	●	●	●																
	Stylus CX 5900																			●	●	●	●																
	Stylus CX 6500	●	●	●	●															●	●	●	●																
	Stylus CX 6900F																			●	●	●	●																
	Stylus CX 7300																			●	●	●	●																
	Stylus CX 8300																			●	●	●	●																
	Stylus CX 9300F																			●	●	●	●																
	Stylus Photo RX 510					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo RX 590																																						
	Stylus Photo RX 610																																						
	Stylus Photo RX 630					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo RX 650					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo RX 690					●	●	●	●	●	●	●									●	●	●	●															
	Stylus TX100																				●	●	●	●															
	Stylus TX101																				●	●	●	●															
	Stylus TX102																				●	●	●	●															
	Stylus TX103																				●	●	●	●															
	Stylus TX105																				●	●	●	●															
	Stylus TX200																				●	●	●	●															
Stylus TX203																				●	●	●	●																
Stylus TX205																				●	●	●	●																
Stylus TX300F																				●	●	●	●																
Stylus TX400																				●	●	●	●																
Stylus TX600FW																				●	●	●	●																
INKJET	Stylus C110																			●	●	●	●																
	Stylus C63	●	●	●	●															●	●	●	●																
	Stylus C65	●	●	●	●															●	●	●	●																
	Stylus C67																			●	●	●	●																
	Stylus C79																			●	●	●	●																
	Stylus C83	●	●	●	●															●	●	●	●																
	Stylus C87																			●	●	●	●																
	Stylus C87+																			●	●	●	●																
	Stylus C90																			●	●	●	●																
	Stylus Photo R1800												●	●	●	●	●	●	●		●	●	●	●															
	Stylus Photo R210					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo R230					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo R270																																						
	Stylus Photo R290					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo R310					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo R350					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo R390					●	●	●	●	●	●	●									●	●	●	●															
	Stylus Photo R800												●	●	●	●	●	●	●		●	●	●	●															
	Stylus T10												●	●	●	●	●	●	●		●	●	●	●															
	Stylus T11												●	●	●	●	●	●	●		●	●	●	●															
Stylus T20												●	●	●	●	●	●	●		●	●	●	●																
Stylus T23																																							